



Application Note

How to use the TOMBAK as a Pulse-Picker

Multiboard Series
TOMBAK : Synchronization electronic board



How to use the TOMBAK as a Pulse Picker

Pre-requirement: Before using the TOMBAK board, make sure you followed all the instructions mentioned in the Operating Manual

1. Introduction / Overview

When someone wants to generate a pulse (open a time domain door) at a low repetition rate (for example Hz/kHz range) which must be synchronized with a high frequency signal/clock (for example 100MHz range), There is two solutions :

1. The most immediate is to divide the clock signal frequency. Using the Tombak for that is described in the first part of this document. **See page 3**
2. When the low frequency pulse/door must also be synchronized with a low frequency external or internal signal (in other word, when we want a low repetition rate pulse at a repetition rate of a low repetition rate trigger BUT synchronized with a high frequency clock), the solution is to use the PICK mode of the Tombak. Note that in this last case, if the low frequency trigger is not synchronized with the high frequency clock, there will be a unavoidable Jitter which value is $1/\text{clock frequency}$. **See page 8**

In both case above, the TOMBAK opens a door with adjustable delays and adjustable width.

Mode 1 : Pulse Picking using the Divider mode

1 Timing Diagram




Figure 1 : Frequency divided, delayed and pulse width adjusted signal from input to output

2. Synoptic





Figure 2 : Main firmware features used in frequency divider mode


3. Cabling

1. Plug the USB-Jack cable in the "USB In" connector
2. Plug the signal generator (i.e. the signal you want to delay) in the "Pulse In" SMA connector
3. The software adjustable delay and pulse width signal will output on the "Pulse Out" SMA connector
4. Finally, plug the power supply to the "Power In" connector to power on the board




4. Software configuration

Launch the ALPhANOV Control Software and click on *Connect* to start the TOMBAK hardware detection. The software automatically detects the TOMBAK board.




A window will appear for each TOMBAK connected to the computer.

The main configuration windows must be configured as follow :




- Working Mode window :
 - Set the **Board On**
 - Set the **Shaper** button to **Off**
 - Set the **Inverse** button to **Off** unless you need to invert the output signal
 - Unset all **Advanced Mode**




- Input pulse window :
 - Configure the **Threshold** voltage so that the input **pulse frequency** is detected and equal to your pulse generator system
 - Set the **Division** factor **according to your application**
 - Set the input pulse **Source** to **Direct**




- Output Pulse window :
 - Choose the output **delay** value
 - Choose the output **pulse width**
 - **Auto Fine Delay** may be let in auto mode




- Synchro input windows :
 - Source : not used in this mode
 - Mode : None
 - Frequency : not used in this mode
 - Burst size : not used in this mode



- Synchro output window (default settings) :
 - Source : Pulse



Don't forget to save the settings by clicking on the "Save" button in the bar menu.



5. Main features

Frequency divider factor	[1 – 10 ⁹]
Adjustable pulse width <ul style="list-style-type: none">▪ resolution (for pulse width [5ns – 510ns])▪ resolution (for pulse width [511ns – 2⁶²ns])	[5ns – >>1000s] 2ns 5ns
Adjustable pulse delay <ul style="list-style-type: none">▪ resolution	[70ns – >>1000s] 10ps
Jitter <ul style="list-style-type: none">▪ for delay < 570ns & pulse width < 510ns▪ for any other delay & pulse width	<200 ps RMS 1.5 ns RMS
Input PulseIn voltage	30 mV – 3,3V
Input maximum frequency	200 MHz
Output Voltage	1 / 3,3 / 5 Volts (hardware setup)
Output maximum frequency	20 MHz

Mode 2 : Pulse Picking using the Pick mode

1. Timing Diagram




Figure 3 : External or internal signal synchronized with Pulse-In signal.

2. Synoptic





Figure 4 : Main firmware features used in synchronization mode

3. Cabling


5. Plug the USB-Jack cable in the "USB In" connector
6. Plug the signal to synchronize in the "Sync Ext in" SMA connector. (only for external signal synchronization). If signal to synchronize is internally generated, no signal needed on "Sync Ext in".
7. Plug the reference signal (i.e. the signal on which "Sync Ext In" signal or

- “internal signal” will be synchronized with) in the “*Pulse In*” SMA connector
- 8. The synchronized signal will output on the “*Pulse Out*” SMA connector
- 9. Finally, plug the power supply to the “*Power In*” connector to power on the board




4. Software configuration

Launch the ALPhANOV Control Software and click on *Connect* to start the TOMBAK hardware detection. The software automatically detects the TOMBAK board.




A window will appear for each TOMBAK connected to the computer.

The main configuration windows must be configured as follow :




- Working Mode window :
 - Set the **Board** On
 - Set the **Shaper** button to **Off**
 - Set the **Inverse** button to **Off** unless you need to invert the output signal
 - Set **Advanced Mode** to **Pick**



- Input pulse window :
 - Configure the **Threshold** voltage so that the input **pulse frequency** is



- detected and the same as your pulse generator system
- Set the **Division** factor to **1**
- Set the input pulse **Source** to **Direct**




- Output Pulse window :
 - Choose the output **delay value**
 - Choose the output **pulse width**
 - **Auto Fine Delay** may be let in auto mode




- Synchro input windows :
 - Source :
 - ⇒ Set **Int** to synchronize an internal generated signal with Pulse-In signal.
 - ⇒ Set **Ext** to synchronize an external signal (connected to Ext-In connector) with Pulse-In signal.
 - Mode : None
 - Frequency :
 - ⇒ If internal source is selected, set the output signal **Frequency** you need to synchronize.
 - ⇒ If external source is selected, **Frequency** shows the input Ext-In signal frequency
 - Burst size : not used in this mode



- Synchro output window (default settings) :
 - Source : Pulse



Don't forget to save the settings by clicking on the "Save" button in the bar menu.



5. Main features

Adjustable pulse width	[5ns – >>1000s]
▪ resolution (for pulse width [5ns – 510ns])	2ns
▪ resolution (for pulse width [511ns – 2 ⁶² ns])	5ns
Adjustable pulse delay	[70ns – >>1000s]
▪ resolution	10ps
Input Ext-In Voltage	
▪ Logic Low	[0-0.8V]
▪ Logic High	[1.7-3.3V]
Input PulseIn voltage	30 mV – 3,3V
Input maximum frequency	200 MHz
Output Voltage	1 / 3,3 / 5 Volts (hardware setup)
Output maximum frequency	20 MHz